



TT

# **HS ARMOR PANEL**

# **FIBERGLASS BALLISTIC PANELS**





## **HS Armor Panels**



Once installed, HS Armor can be finished with (or covered by) a variety of wall treatments.



HS Armor panels are available in sheets up to 4' in width and in any practical length.

Strongwell's HS Armor fiberglass armor panels are designed for ballistics resistance. The panels are manufactured using specially constructed glass reinforcements in a proprietary resin matrix. The panel components are then cured in a controlled cycle.

When struck by a bullet or other projectile, HS Armor panels delaminate in a way that absorbs the energy and stops the projectile. Thousands of these panels have been purchased by the military, law enforcement, and numerous private and public sector organizations to provide an extra layer of protection for its people.

Panels are available in any length practical, widths up to 4', and in thicknesses from  $\frac{1}{4}$ " to  $\frac{1}{2}$ ". Strongwell typically tests panels in accordance with the 11<sup>th</sup> Edition of Underwriters Laboratories (UL) 752 requirements for Levels 1-8 (including Supplementary Shotgun), although other options are available upon request.

### **Common Applications:**

- Judge's Benches
- Jury Boxes
- Convenience Stores
- Classrooms

### Bank Teller Areas

- Panic Rooms and Safe Rooms
- Storm Shelters
- Office Buildings

# **HOW TO SPECIFY**

Panels shall be HS Armor as manufactured by Strongwell. Panels shall be manufactured in the U.S.A. using the pultrusion process. Resin shall be fire-retardant polyester. Panels shall meet the ballistic performance requirements of (UL 752 Level \_\_\_, 11<sup>th</sup> Edition) (other custom requirement).

### **HOW TO ORDER**

In addition to indicating panel width and length dimensions (max panel width is 4' in any length practical), it is vital to indicate the ballistic performance required, which will determine panel thickness and configuration. Panels, as manufactured, range in thickness from  $\frac{1}{4}$ " to  $\frac{1}{2}$ ". If final thickness is to be greater than  $\frac{1}{2}$ ", panels must be layered to meet more demanding ratings. For panels greater than  $\frac{1}{2}$ " thick, indicate whether panels are to be bonded or will be layered/bonded in the field during installation.





HS Armor can be finished to imitate drywall, as was done in the waiting area of this municipal building.

# **TESTING & REQUIREMENTS**

Strongwell HS Armor panels are internally tested on a regular basis for conformance to the 11<sup>th</sup> Edition of Underwriters Laboratories (UL) 752 requirements and independently tested to verify results. Testing data is available upon request.

Additionally, HS Armor panels can be tested to a number of other domestic and international ballistic standards and protocols (NIJ, SD, MIL, etc.), or to a set of specific customer performance requirements.

Regarding fire performance, HS Armor panels are self-extinguishing and meet a UL 94 V-0 flammability rating.

APPROX. PANEL Thickness (In.)	UL 752 RATING	WEAPON	AMMUNITION	VELOCITY (FT/SEC.)	NO. OF Shots	APPROX. WEIGHT (PSF)
0.25	Level 1	9mm Luger	124gr. FMJ	1175 - 1293	3	2.51
0.35	Level 2	.357 Magnum	158gr. JSP	1250 - 1375	3	4.10
0.50	Level 3	.44 Magnum	240gr. Lead	1350 - 1485	3	5.10
1.50 <sup>2</sup>	Level 4	.30 Caliber (.30-06)	180gr. Soft Point	2540 - 2794	1	15.30
1.50 <sup>2</sup>	Level 5	7.62mm (.308 Caliber)	150gr. FMJ	2750 - 3025	1	15.30
0.50	Level 6	9mm Luger	124gr. FMJ	1400 - 1540	5	5.10
1.00 <sup>1</sup>	Level 7	5.56mm (.223 Caliber)	55gr. FMJ	3080 - 3388	5	10.20
1.50 <sup>2</sup>	Level 8	7.62mm (.308 Caliber)	150gr. FMJ	2750 - 3025	5	15.30
0.50	Supplementary Shotgun	12-Gauge	1 oz. Rifled Slug	1585 - 1744	3	5.10
0.50	Supplementary Shotgun	12-Gauge	1.5 oz. 00 Buckshot (12 pellets)	1200 - 1320	3	5.10

### UL 752 Requirements (11th Edition)

**NOTES:** <sup>1</sup> This configuration consists of two 0.50" panels, which shall be bonded together utilizing Strongwell's HS Armor bonding guidelines, available upon request. <sup>2</sup> This configuration consists of three 0.50" panels, which can be bonded together.

FMJ - Full Metal Jacket JSP - Jacketed Soft Point SWC - Semi-Wadcutter LRHV - Long Rifle High Velocity RN - Round Nose



**Front View** 



**Rear View** 

# **FABRICATION & INSTALLATION**

### **Cutting, Drilling, and Attachment**

Strongwell's HS Armor panels can be cut and drilled using ordinary carpenter's tools. A carbide or diamond grit edge blade is recommended for cutting. It is recommended to use high speed drill bits at slow speeds when drilling - carbide tipped drills are best for all drilling operations.

Installation and attachment of panels to existing structures is easily accomplished with bolts, screws, or industrial grade adhesive.

### **Adhesives**

HS Armor panels can be attached to most substrates with adhesives, such as construction adhesive. For stronger adhesion, especially to non-porous substrates, including aluminum, steel and stainless steel, a two-part epoxy is recommended.

Adhesives should be used per the adhesive manufacturer's instructions.

### **Painting**

HS Armor panels can be painted using high quality water- or oilbased paints. Urethane and epoxy paints/coatings will provide a more durable finish. For external applications, a paint with a UV inhibitor should be used to protect the armor panels from longterm UV exposure.

### **Wall Assembly Installation**

For typical wall and millwork installations, a 4" wide batten strip of the same thickness material should be specified at the butt-joints to provide a minimum of 2" overlap from one panel to the next. Batten strips can be cut in the field from panels, or can be ordered from Strongwell.

Batten strips can be attached directly to the panels and should be used where any vertical or horizontal joints occur. Battens are not required in a  $90^{\circ}$  corner, as long as the panels overlap (see diagram).

Any required battens should be placed between studs, so the wall does not protrude out from studs farther than necessary and panels can be attached directly to studs.



**NOTE:** For laminated panel configuration, contact Strongwell for guidance in proper installation.





ISO 9001 Quality Certified Manufacturing Plants

BRISTOL LOCATION 400 Commonwealth Ave., Bristol, VA 24201 USA (276) 645-8000 www.strongwell.com